

SPECIFICATIONS

Max power output:	1.7 watts
Max sound output:	98 dB at 1m
Batteries:	4 x AA alkaline non-rechargeable
Water Resistance:	IP65
Temperature range:	-20C to +55C
Battery life:	30-60 days

DECLARATION OF CONFORMITY

QTIME Ltd declare that the product: Model: Tweetee is in conformity with the provisions of the following EU directive: Electromagnetic Compatibility Regulations 2014/30/. EN 61000-6-3:2007 Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light- industrial environments. EN 61000-6-1:2007 Electromagnetic compatibility (EMC) - Part 6-1: Generic standards - Immunity for residential, commercial and light-industrial environments. Restriction of Hazardous Substances Directive 2011/65/EU. EN 50581 Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances. This declaration of conformity is issued under the sole responsibility of the manufacturer.

Tweetee complies with Part 15 of the FCC Rules and Regulations for Information Technology Equipment. Operation is subject to the following two conditions: (1) these devices may not cause harmful interference, and (2) these devices must accept any interference received, including interference that may cause undesired operation.

FD Responsible Party: Qtime Ltd, 1001 Fischer Blvd. Ste 3 PMB 1006. Toms River, NJ 08753-3818 USA

Contact Person: Keith Potter Contact Email: keith.potter@getqtime.com

Equipment Class: FCC Part 15 Class B Product Type: Bird Scarer

We, the responsible party Qtime Ltd, declare that the product Tweetee was tested to conform to the applicable FCC rules and regulations. The method of testing was in accordance with the appropriate measurement standards, and all necessary steps have been taken to ensure that all production units of these devices will continue to comply with the Federal Communications Commission's requirements.

K A Potter

Keith Potter. Director Qtime Ltd. 10th January 2024

Qtime Ltd. Unit 2. 6 Temple Street. Sidmouth. Devon. EX1 9AY UK

1001 Fischer Blvd. Ste 3 PMB 1006. Toms River, NJ 08753-3818 USA

www.tweetee.uk Contact: info@tweetee.uk



HOW TWEETEE WORKS

- Tweetee will attract birds looking for a nest site by playing naturally recorded bird calls for 2 hours after dawn.
- Tweetee comes in three models for Swifts (UK), House Martins (UK) and Purple Martins (US and Canada)
- Tweetee reduces the effects of familiarity by playing a number of different bird call sequences.
- The Tweetee device sleeps between bird calls saving battery power.
- Simply mount the unit next to the nesting box using the button and screw supplied. Turn on and adjust the volume to suit.

ATTRACTING NESTING BIRDS

Swifts, House Martins and Purple Martins search out nesting sites from spring to early summer. Tweeet attracts birds to the nest box by playing recorded bird calls just after dawn. Immature birds may return to the nest site next season.

GETTING STARTED

- Fix the supplied green button on a vertical surface near the nesting box and hook the unit on the button. Batteries are already inside.
- When it's dark and after dusk, press the power button.
- The red led will light, then the unit will play a bird call, then an owl if its dark. If you hear a cockerel, then it's still too light. Thereafter, Tweeet will play calls for two hours after dawn.
- Pressing the volume button for more than 2 seconds will adjust the sound output level. The highest tone is the loudest.
- We recommend the unit is dry-stored out of nesting season.

BATTERY REPLACEMENT

- The unit will play a warning message if the battery is getting low or you may notice the bird calls start to appear distorted.
- Depending on the hours of daylight, temperature and volume, the batteries will last around 30 to 60 days.
- To replace, first turn the unit off. Then unscrew the four Philips screws on the front of the unit and keep safe.
- Replace the **4 x AA** alkaline batteries.
- Ensure the white seal on the lid is fully home in its slot.
- Screw the four Philips screws back into the unit. The screws need to be tightened quite firmly. Ensure the white seal in lid is fully home.

CHANGING VOLUME

Tweeet will play the bird calls around the same volume as the actual bird call. Press and hold the volume button for more than 2 seconds to adjust. The highest tone played is the loudest. The unit will store its volume setting if the batteries are changed.

NIGHT AND DAY

Tweeet will automatically by default turn off at night and come on at dawn the following morning for two hours. To enable continuous operation in all light levels: Turn the unit on and after the initial call is played, press the volume button down for more than 2 secs and let the unit cycle through the tones. When you get the loudest, highest tone, take your finger off the button and leave the unit for a few seconds. Then press the volume down again, and you will hear the same tone again. Keep your finger on the button for three complete cycles (meaning you hear the highest tone initially and then three more times). When you hear the tone for the last time take your finger off the button immediately and you will hear an owl play. This means the box will run regardless and ignore the light sensor. To return to normal operation, repeat the above to hear a cockerel sound. Note that in continuous operation batteries will last around 80 hours.

TROUBLE SHOOTING

- No sounds and flashing red LED: the unit has an internal error.
- Warning message followed by 10 secs of red flashing: low battery.
- Distorted bird songs: low battery.
- No sounds: Make sure the unit is in good, external daylight.
- To reset the unit, turn off for a few minute and turn on after dark
- Sounding later in day or not a dawn: Reset the unit
- If you do have any issues, please email us at info@tweeet.uk